









Installation instruction





tyco
 Thermal Controls

European Headquarters
 Tyco Thermal Controls
 Romeinse Straat 14
 3001 Leuven
 Belgium
 Tel. (32) 16 213 511
 Fax (32) 16 213 610

www.tycothermal.com